



HARDWARE

USER MANUAL

WWW.UNICORE.COM

UM68X Series Modules Evaluation Board

Copyright© 2009-2025, Unicore Communications, Inc.
Data subject to change without notice.

Revision History

Version	Revision History	Date
R1.0	First Release.	Nov., 2025

Legal right notice

This manual provides information and details on the products of Unicore Communication, Inc. ("Unicore") referred to herein.

All rights, title and interest to this document and the information such as data, designs, layouts contained in this manual are fully reserved, including but not limited to the copyrights, patents, trademarks and other proprietary rights as relevant governing laws may grant, and such rights may evolve and be approved, registered or granted from the whole information aforesaid or any part(s) of it or any combination of those parts.

Unicore holds the trademarks of “和芯星通”, “UNICORE”, “UNICORECOMM” and other trade name, trademark, icon, logo, brand name and/or service mark of Unicore products or their product serial referred to in this manual (collectively “Unicore Trademarks”).

This manual or any part of it, shall not be deemed as, either expressly, implied, by estoppel or any other form, the granting or transferring of Unicore rights and/or interests (including but not limited to the aforementioned trademark rights), in whole or in part.

Disclaimer

The information contained in this manual is provided “as is” and is believed to be true and correct at the time of its publication or revision. This manual does not represent, and in any case, shall not be construed as a commitments or warranty on the part of Unicore with respect to the fitness for a particular purpose/use, the accuracy, reliability and correctness of the information contained herein.

Information, such as product specifications, descriptions, features and user guide in this manual, are subject to change by Unicore at any time without prior notice, which may not be completely consistent with such information of the specific product you purchase.

Should you purchase our product and encounter any inconsistency, please contact us or our local authorized distributor for the most up-to-date version of this manual along with any addenda or corrigenda.

Foreword

This manual provides information on the hardware composition and design of Unicore UM68X series EB (Evaluation Board).

Target Readers

This document is written for technicians who are familiar with GNSS modules.

Contents

1	Introduction.....	1
1.1	Block Diagram.....	1
1.2	Appearance	3
2	Interfaces	5
3	Power Supply.....	7
3.1	3.3 V LDO Power Supply.....	8
3.2	5 V DCDC Power Supply	9
3.3	Backup Power Supply.....	10
4	Antenna Circuit.....	12
4.1	Antenna Detection Circuit	12
4.2	Antenna Feed Circuit	13
5	LED Indicators	15
6	Peripheral Design	16
7	Debug Support	20
	Appendix.....	21

1 Introduction

This manual introduces Unicore UM68X series EB (Evaluation Board) and applies to:

- UM681A-12-EB
- UM680A-12-EB
- UM680A-13-EB
- UM681-12-EB
- UM680-12-EB

For the information of each module, refer to the corresponding user manual.

The EB consists of the following parts:

- positioning module
- a 3.3V LDO (Low Dropout Regulator)
- a 5V DC/DC boost circuit
- an antenna detection circuit
- peripheral interfaces

1.1 Block Diagram




Figure 1-1 UM680A EB Block Diagram¹

¹ UM680A, hardware version V1.1 and above, supports antenna detection and SPIM. I²C and EVENT




Figure 1-2 UM681A EB Block Diagram²

interfaces are not supported.

² UM681A, hardware version V1.1 and later, supports antenna detection. I²C and EVENT interfaces are not supported.

1.2 Appearance

The appearance of the EB is shown as the figure below.




Figure 1-3 Top View

- (1) Silkscreen: It marks the signals of the pins. The smaller holes around are used to mount the module socket. The printing adopts exposed copper to ensure the flatness of the surface.
- (2) Positioning module: The pin pads are designed long, which is convenient for soldering, testing and debugging. For detailed packaging information, please refer to the PCB document.
- (3) PPS connector: To measure the PPS signal, solder an MMCX connector here.
- (4) LED indicators: Indicating the status of the power supply, reset, antenna short circuit, the positioning status and UART.

☞ To facilitate testing, the dimensions of the module's functional pin pads on the EB are extended outside the module package boundary.

☞ This design applies only to testing scenarios and is not recommended to be directly used in mass production or formal product design.

☞ For formal product design, the dimensions and layout of the pin pads need to be optimized in accordance with SMT process requirements to ensure optimal manufacturability and reliability.




Figure 1-4 Bottom View

- | | |
|---|--|
| (1) External antenna detection circuit ³ | (5) 5 V antenna feed DCDC boost circuit |
| (2) ESD protection and exposed copper thermal dissipation | (6) Dual-row pins as external interfaces |
| (3) VCC power supply and LDO voltage regulator circuit | (7) Debug ports |
| (4) Backup battery | (8) Ports used to connect jumpers |

³ Supported by hardware version V1.1 and above.

2 Interfaces

The dual-row 28 pins serve as the external interfaces of the EB, and the pin pitch is 2 mm. The interfaces can be directly connected to the J18 on Unicore HPL EVK-V5.0 board.

 The availability of the ports depends on the model of the module and its firmware. Refer to 1.1 Block Diagram and the corresponding user manuals for more information about the supported ports.




Figure 2-1 Interfaces

Table 2-1 Interfaces Description

No.	Pin Name	I/O	Description
1	SPIM_MOSI	O	Master out/slave in.
2	SPIM_CSN	O	SPI master chip select.
3	SPIM_CLK	O	SPI master clock.
4	NC	—	No connection inside.
5	LNA_PWR	I	Antenna feed voltage for LNA.
6	VIN	I	Main power supply.
7	SPIM_MISO	I	Master in/slave out.
8	RSV	—	Reserved. Leave floating.
9	RESET_N	I	System reset, active low. The active time should be no less than 5 ms.
10	NC	—	No connection inside. Leave floating.
11	EVENT ⁴	I	Event input with adjustable frequency and polarity.
12	WT	I	The odometer speed pulse input pin on the UM681A/UM681 supports a maximum pulse frequency of 5 kHz, with a minimum pulse width greater than 100 μs. On the UM680A/UM680, this pin is left floating.

⁴ Reserved interface and not supported.

No.	Pin Name	I/O	Description
13	RSV	—	Reserved. Leave floating.
14	GND	—	Ground.
15	TXD1	O	UART1 output; LVTTL.
16	RXD1	I	UART1 input; LVTTL.
17	GND	—	Ground.
18	TXD2	O	UART2 output; LVTTL.
19	RXD2	I	UART2 input; LVTTL.
20	GND	—	Ground.
21	RSV	—	Reserved. Leave floating.
22	GND	—	Ground.
23	PPS	O	Pulse per second with adjustable pulse width and polarity.
24	DIR	I	The odometer direction input pin on the UM681A/UM681: High level = forward; Low level = reverse. On UM680A/UM680, this pin is left floating.
25	RTK_STAT ⁵	O	RTK Positioning Indicator (active-high): high when RTK fixed solution is valid; low otherwise (including other positioning modes or no fix).
26	RSV	—	Reserved. Leave floating.
27	SDA ⁶	I/O	I ² C Data.
28	SCL ⁶	I/O	I ² C Clock.

⁵ Reserved interface and not supported.

⁶ I²C is a reserved interface and not supported.

3 Power Supply

The power supply of the EB is input from the VIN pin, passing through a circuit with surge protection and filter capacitors, to provide power for the 3.3 V LDO circuit and 5 V DC/DC boost circuit.

The input range of VIN is 3.2 V to 5 V.




Figure 3-1 Power Filter Circuit




Figure 3-2 3.3 V LDO and 5 V DC/DC on the Bottom

3.1 3.3 V LDO Power Supply

VCC outputs 3.3 V voltage after passing through the LDO circuit to provide power to the EB.




Figure 3-3 3.3 V LDO Power Supply

Design and usage guidelines for the LDO circuit are as follows:

- The rated output current of LDO should be more than twice the current of the module.
- R38 is a series resistor placed at the input of the LDO, which is used for debugging. When selecting the resistor, choose one with high rated power to ensure the current capability. Here, a 0805 0-ohm resistor is selected.
- R39 is a resistor connected in parallel with LDO. After removing R38 and soldering R39, you can use VCC to power the module.

👉 When using the LDO to power the module, you should consider the power dissipation of the LDO.

3.2 5 V DCDC Power Supply

VCC outputs 5 V voltage after passing through the DC/DC boost circuit to feed the antenna.




Figure 3-4 5 V DCDC Boost Circuit

Antenna feed power configuration and debugging guidelines are as follows:

- You can choose whether to use the 5 V power on the board to feed the antenna according to the antenna type.
- R61 and R76 are series resistors connected to the DC/DC circuit at the input and output, which are used for debugging. When selecting the resistors, choose those with suitable rated power according to the power consumption of the antenna load. Here, a 0603 0-ohm resistor is selected.
- R77: After removing R61/R76 and soldering R77, you can use the external LNA_PWR to feed the antenna.

3.3 Backup Power Supply

When using the hot start function of the EB, you need to provide backup power for the module.

The input range of V_BCKP is 2.0 V to 3.6 V.




Figure 3-5 Backup Power Supply




Figure 3-6 Backup Power Circuit on the Bottom

Design and test guidelines for the V_BCKP backup power supply are as follows:

- When the backup battery supplies power to V_BCKP, the battery charging circuit should be designed to prevent reverse current to ensure that the battery only supplies power to V_BCKP and the current does not flow back into the 3.3 V power domain, as the D52 shows in [Figure 3-5](#).
- According to the maximum charging current of the battery, a current-limiting resistor should be added, as the R84 shows in [Figure 3-5](#).
- V_BCKP can also be powered through the test point TP9. Removing R85, connecting a power supply wire at TP9 and a ground wire at TP6, you can use an external power to supply V_BCKP. This method can be used to measure the supply voltage and current of V_BCKP.

UM68X Series Evaluation Board User Manual

- In the case of normal power supply to the EB, the micro battery charging circuit on the board will automatically charge the micro battery.
- If the EB has been placed for a long time, the power of the battery may be low and the hot start test may fail. Therefore, it is recommended to charge the board as long as possible before testing the hot start function. Battery status assessment and charging characteristics are as follows:
 - Use a multimeter to measure the voltage of the micro battery. If the voltage is above 2.6 V and is stable, it indicates that the power of the micro battery is sufficient.
 - Use a multimeter to measure the voltage of the micro battery. If the voltage drops rapidly, it indicates that the power of the micro battery is insufficient.
 - When the micro battery runs out of power, it will take more than 96 hours to fully charge the battery.
 - Under normal circumstances, after powering the EB for one night, the hot start test can be done normally the next day.

4 Antenna Circuit

4.1 Antenna Detection Circuit ⁷

The antenna detection circuit consists of a MOS switch, a current detection chip and two buffers.

The antenna feed supply can be selected from the 5 V DC/DC circuit output or VCC_RF (supplied by the module). VCC_RF provides 3.3 V voltage, but the circuit has less protective design; therefore, it is not recommended to use VCC_RF to supply power to the antenna.

U6 and U2 are two buffers with open-drain output. ANT_OFF1 needs to be pulled up through ANT_BIAS1 to make sure that MOS can be turned off.

The current threshold can be adjusted by changing the resistance value of R24/R13/R14. Since the feed current flowing through R24 will generate a voltage drop, this solution is not suitable for antennas with high power consumption.




Figure 4-1 Antenna Detection Circuit

Table 4-1 Truth Table of the Antenna Detection Circuit

ANT-OFF	ANT-DETECT	ANT-SHORT-N	
1	X	X	The antenna feed supply is turned off
0	0	0	An error occurred in the circuit
0	0	1	No antenna detected
0	1	0	The antenna feed circuit is shorted to ground

⁷ Supported by hardware version V1.1 and above.

ANT-OFF	ANT-DETECT	ANT-SHORT-N	
0	1	1	The antenna status is normal




Figure 4-2 Antenna Detection Circuit on the Bottom

4.2 Antenna Feed Circuit

The antenna feed circuit consists of the anti-reverse current design, anti-surge design, filter inductors, and ESD protection.

The supply voltage can be selected from 5 V, VCC_RF or ANT_BIAS3 through R31/R29/R30. When using the 5 V voltage or VCC_RF, the antenna detection circuit on the EB will be bypassed.

The ESD protection diode should support high-frequency signal (above 2000 MHz). Nexperia PESD5V0F1BL is recommended here.




Figure 4-3 Antenna Feed Circuit




Figure 4-4 Antenna Feed Circuit on the Bottom

5 LED Indicators

There are LED indicators on the EB to indicate the working status of each functional unit.




Figure 5-1 LED Indicators

Table 5-1 Description of the LED Status

LED Indicator	Color	Description
Power (5V or 3.3V)	Green	Light on when the power is normal
Reset	Red	Light on when pressing the reset button
Antenna ⁸	Red	Light on when antenna is shorted
RTK ⁹	Green	Light on when RTK is fixed
UART	Green	Blinking when UART is working

The silkscreen markings on the right of the LED indicators identify the corresponding functions, as shown in [Figure 5-2 Markings on the Right of the LED Indicators](#).




Figure 5-2 Markings on the Right of the LED Indicators


⁸ Supported by hardware version V1.1 and above.

⁹ RTK indicator is not supported.

6 Peripheral Design

Recommended hardware design practices are as follows:

- Add TVS anti-surge protection at the input of the module. Add ESD protection at all pins.
- Use large and small VCC filter capacitors together. A combination of 10 μF , 0.1 μF , and 100 pF is recommended.
- Add series resistors at the IO pins for the convenience of debugging.
- VCCIN powers the module only. R33 is a large-size resistor (with high rated power) to ensure the current capability. A 0805 resistor is used for the design in this chapter.
- Removing R33, connecting a power supply wire at TP1 and a ground wire at TP3 (as shown in [7 Debug Support](#)), you can use an external power to supply the module. This method can be used to measure the input voltage and current of the module.

 R33, TP1, and TP3 refer to the resistor and test points on the evaluation board, respectively. Their exact locations are shown in Appendix.

The figures below show the peripheral circuit design for the UM68X series modules.

UM68X Series Evaluation Board User Manual




Figure 6-1 UM680A Peripheral Design (V1.0)




Figure 6-2 UM680A Peripheral Design (V1.3)




Figure 6-3 UM681A Peripheral Design (V1.0)




Figure 6-4 UM681A Peripheral Design (V1.3)

The availability of the ports depends on the model of the module and its firmware. Refer to 1.1 Block Diagram and the corresponding user manual for more information about the supported ports.

UM68X Series Evaluation Board User Manual

Silkscreen markings are printed around the module to identify the resistors, which is convenient for measurement.




Figure 6-5 Peripheral Circuit

The GND pads at the bottom of the module should be grounded to ensure heat dissipation. The EB has copper exposed on the bottom of the module, which not only enhances heat dissipation, but also provides a large area for grounding and is convenient to test.




Figure 6-6 Pads (Y1-Y52) and Socket Mounting Holes (X1-X8)

7 Debug Support

As mentioned above, TP1 and TP9 can be used to connect an external power to supply VCCIN and V_BCKP and to measure the supply voltage and current.

TP2, TP3, TP5 and TP7 are used for internal debugging, of which TP5 and TP7 can be used to debug I²C.

J1 is used for MMCX connection. After soldering the MMCX connector, it can be used to measure the PPS signals.

J2, J3, J6 and J7 are debug ports. Connect the signal that needs to be tested to the square hole and test the round hole, or connect the round hole to a measuring instrument. Using these debug ports can avoid damage to the PCB pads and traces, which is convenient for debugging.




Figure 7-1 Debug Ports for the Module

The silkscreen markings on the right of the test points are arranged in order to identify the function of each port.

UM68X Series Evaluation Board User Manual





Figure 7-2 Through-Hole Test Points


Appendix

Schematic of the EB:

Assembly Top of the EB



23



和芯星通科技（北京）有限公司

Unicore Communications, Inc.

北京市海淀区丰贤东路 7 号北斗星通大厦三层
F3, No.7, Fengxian East Road, Haidian, Beijing, P.R.China,
100094

www.unicore.com

Phone: 86-10-69939800

Fax: 86-10-69939888

info@unicorecomm.com



www.unicore.com