



HARDWARE

REFERENCE DESIGN

[WWW.UNICORE.COM](http://WWW.UNICORE.COM)

# UM760 Series

Multi-GNSS Single-Frequency  
Positioning Module

Copyright© 2009-2026, Unicore Communications, Inc.

Data subject to change without notice.



# Foreword

## About This Document

---

This manual provides the schematic diagrams, hardware design considerations, and recommended BOM for the Unicore UM760 series modules.

### Target Readers

This manual is intended for technical personnel familiar with GNSS receivers.

## Statement

---

### Legal right notice

This manual provides information and details on the products of Unicore Communication, Inc. ("Unicore") referred to herein.

All rights, title and interest to this document and the information such as data, designs, layouts contained in this manual are fully reserved, including but not limited to the copyrights, patents, trademarks and other proprietary rights as relevant governing laws may grant, and such rights may evolve and be approved, registered or granted from the whole information aforesaid or any part(s) of it or any combination of those parts.

Unicore holds the trademarks of "和芯星通", "Unicore", "UNICORECOMM" and other trade name, trademark, icon, logo, brand name and/or service mark of Unicore products or their product serial referred to in this manual (collectively "Unicore Trademarks").

This manual or any part of it, shall not be deemed as, either expressly, implied, by estoppel or any other form, the granting or transferring of Unicore rights and/or interests (including but not limited to the aforementioned trademark rights), in whole or in part.

### Disclaimer

The information contained in this manual is provided "as is" and is believed to be true and correct at the time of its publication or revision. This manual does not represent, and in any case, shall not be construed as a commitments or warranty on the part of Unicore with respect to the fitness for a particular purpose/use, the accuracy, reliability and correctness of the information contained herein.

Information, such as product specifications, descriptions, features and user guide in this manual, are subject to change by Unicore at any time without prior notice, which may not be completely consistent with such information of the specific product you purchase.



Should you purchase our product and encounter any inconsistency, please contact us or our local authorized distributor for the most up-to-date version of this manual along with any addenda or corrigenda.



# Revision History

Version	Revision History	Date
R1.0	First release.	Mar. 2026

## Document Status

Releases	Status Descriptions	Current Status
Primary	This is a pre-release version with target specifications that are subject to revision.	
Alpha release	This is an alpha release version, which has been preliminarily tested and verified. The content may undergo minor modifications based on user feedback and further testing.	
Production release	The document contains the complete and final specifications.	√

# 1 Reference Circuit Using an Active Antenna

- The voltage range of VCC and V\_BCKP are described in [Power Supply Requirements](#).
- Ground all GND pins of the module.
- Connect the RF\_IN signal to the antenna and ensure 50  $\Omega$  impedance matching.
- Use an external power supply to feed the antenna.

If the antenna's power supply and the module's main power supply (VCC) use the same power rail, the ESD, surge and overvoltage introduced at the antenna will be directly applied to VCC, which may cause damage to the module. Therefore, it's recommended to design an independent power rail for the antenna to reduce the possibility of damage to the module.




Figure 1-1 Reference Circuit Using an Active Antenna

## 2 Reference Circuit Using a Passive Antenna

- The voltage range of VCC and V\_BCKP are described in [Power Supply Requirements](#).
- Ground all GND pins of the module.
- For optimal system performance when using a passive antenna, an LNA (Low-Noise Amplifier) is required between the antenna and the module's RF\_IN pin.
- Ensure 50  $\Omega$  impedance matching for the RF routing (antenna  $\rightarrow$  LNA  $\rightarrow$  RF\_IN).




Figure 2-1 Reference Circuit Using a Passive Antenna

## 3 Power Supply Requirements

### 3.1 Main Supply (VCC)

---

The voltage range of VCC is 2.7 V ~ 3.6 V.

**Notes:**

- The initial level of VCC when powered on needs to be less than 0.4 V.
- The power-on ramp of VCC needs to be monotonic, without plateaus.
- The undershoot and ringing of VCC when powered on need to be within 5% of VCC.
- Power-on waveform: The time interval from 10% rising to 90% needs to be within 100  $\mu$ s ~ 10 ms.
- Power-on time interval: The time interval between the power-off (VCC < 0.4 V) to the next power-on is recommended to be larger than 500 ms.

### 3.2 Backup Supply (V\_BCKP)

---

When using hot start, backup power supply is required for the module. The voltage range of V\_BCKP is 1.7 V ~ 3.6 V.

**Notes:**

- The initial level of V\_BCKP when powered on needs to be less than 0.4 V.
- The power-on ramp of V\_BCKP needs to be monotonic, without plateaus.
- The undershoot and ringing of V\_BCKP when powered on need to be within 5% of V\_BCKP.
- Power-on waveform: The time interval from 10% rising to 90% needs to be within 100  $\mu$ s ~ 10 ms.
- Power-on time interval: The time interval between the power-off (V\_BCKP < 0.4 V) to the next power-on is recommended to be larger than 500 ms.
- The V\_BCKP pin cannot be floating or connected to ground. When hot start is not used, V\_BCKP must be connected to VCC or backup power.



## 4 Recommended BOM

Table 4-1 Recommended BOM

	Component	Order No.	Manufacturer
U1	RS-232 Transceivers	TRS3122ERGER	TI
U2	LNA	MXDLN14TP	MAXSCEND

和芯星通科技（北京）有限公司

**Unicore Communications, Inc.**

北京市海淀区丰贤东路 7 号北斗星通大厦三层  
F3, No.7, Fengxian East Road, Haidian, Beijing, P.R.China,  
100094

[www.unicore.com](http://www.unicore.com)

Phone: 86-10-69939800

Fax: 86-10-69939888

info@unicorecomm.com



[www.unicore.com](http://www.unicore.com)