



INSTALLATION AND OPERATION

USER MANUAL

WWW.UNICORE.COM

UM680A

Automotive Grade GNSS High Precision RTK Positioning Module

Revision History

Version	Revision History	Date
R1.0	First release.	Aug. 2025



Legal Right Notice

This manual provides information and details on the products of Unicore Communication, Inc. ("Unicore") referred to herein.

All rights, title and interest to this document and the information such as data, designs, layouts contained in this manual are fully reserved, including but not limited to the copyrights, patents, trademarks and other proprietary rights as relevant governing laws may grant, and such rights may evolve and be approved, registered or granted from the whole information aforesaid or any part(s) of it or any combination of those parts.

Unicore holds the trademarks of "和芯星通", "Unicore", "UNICORECOMM" and other trade name, trademark, icon, logo, brand name and/or service mark of Unicore products or their product serial referred to in this manual (collectively "Unicore Trademarks").

This manual or any part of it, shall not be deemed as, either expressly, implied, by estoppel or any other form, the granting or transferring of Unicore rights and/or interests (including but not limited to the aforementioned trademark rights), in whole or in part.

Disclaimer

The information contained in this manual is provided "as is" and is believed to be true and correct at the time of its publication or revision. This manual does not represent, and in any case, shall not be construed as a commitments or warranty on the part of Unicore with respect to the fitness for a particular purpose/use, the accuracy, reliability and correctness of the information contained herein.

Information, such as product specifications, descriptions, features and user guide in this manual, are subject to change by Unicore at any time without prior notice, which may not be completely consistent with such information of the specific product you purchase.

Should you purchase our product and encounter any inconsistency, please contact us or our local authorized distributor for the most up-to-date version of this manual along with any addenda or corrigenda.

Foreword

This document describes the information of the hardware, package, specification and the use of Unicore UM680A module.

This is only a draft version, for reference only.

Target Readers

This document applies to technicians who are familiar with GNSS receivers.

Contents

1	Introduction	1
1.1	Key Specifications	2
1.2	Block Diagram	4
2	Hardware	5
2.1	Pin Definition	5
2.2	Electrical Specifications	8
2.2.1	Absolute Maximum Ratings	8
2.2.2	Operational Conditions	9
2.3	Dimensions	10
3	Hardware Design	12
3.1	Recommended Minimal Design	12
3.2	Antenna Feed Design	12
3.3	Antenna Detection Design	14
3.4	Power-on and Power-off	14
3.5	Grounding and Heat Dissipation	15
3.6	Recommended Footprint on the PCB	16
4	Production Requirements	17
4.1	Clean	17
4.2	Soldering	17
4.3	Stencil	18
5	Packaging	19
5.1	Label Description	19
5.2	Ordering Information	19
5.3	Product Packaging	20

1 Introduction

UM680A is an automotive-grade GNSS navigation and positioning module designed for intelligent driving field. It is based on the multi-system, dual-frequency and high-performance GNSS SoC - UC6580A, which conforms to the requirements of AEC-Q100, and the manufacturing process is in line with IATF 16949.

UM680A supports GPS/BeiDou/GLONASS*/Galileo/QZSS/NavIC* and L1+L5 frequency, providing RTK centimeter-level positioning function. It has two sub-models, UM680A-12 and UM680A-13 respectively, among which the working temperature of UM680A-13 supports 105 °C. See **Table 1-1** for more information.





Figure 1-1 UM680A High Precision Positioning Module

* Only supported by the specific firmware.

1.1 Key Specifications

Table 1-1 Technical Specifications

Products	UM680A-12 Multi-system dual-frequency high precision RTK positioning module	UM680A-13 Multi-system dual-frequency high precision RTK positioning module
Illustration		
Dimension	22.0 mm × 17.0 mm × 2.6 mm	22.0 mm × 17.0 mm × 2.6 mm
Package	54 pin LGA	54 pin LGA
Working Temperature	-40 °C to +85 °C	-40 °C to +105 °C
Storage Temperature	-40 °C to +85 °C	-40 °C to +105 °C
RF Input		
Frequency	GPS: L1C/A+L5 BDS: B1I+B1C*+B2a Galileo: E1+E5a GLONASS: G1* NavIC: L5* QZSS: L1+L5 SBAS	GPS: L1C/A+L5 BDS: B1I+B1C*+B2a Galileo: E1+E5a GLONASS: G1* NavIC: L5* QZSS: L1+L5 SBAS
VSWR	≤ 2.5	≤ 2.5
Input Impedance	50 Ω	50 Ω
Antenna Gain	15 dB to 30 dB	15 dB to 30 dB
Interface		
UART ¹	×2	×2
I ² C ²	●	●
SPI ³	●	●
PPS	×1	×1
EVENT	×1	×1

* Supported by the specific firmware.

¹ TTL; baud rate: 115200 to 921600 bps.

² Reserved; address: 7 bit; working mode: slave; supports 400 Kbps at most

³ UM680A has an SPIM and an SPIS, where SPIS is reserved (sharing pin 42 to 45 with UART and I2C). The maximum transfer rate of SPIS is 4 Mbps and that of SPIM is 16 Mbps.

UM680A User Manual

Products	UM680A-12 Multi-system dual-frequency high precision RTK positioning module	UM680A-13 Multi-system dual-frequency high precision RTK positioning module
RESET_N	●	●
RTK_STAT	●	●
GNSS Antenna	×1	×1
Performance		
TTFF	Cold start: 26 s Hot start: 2 s Reacquisition: 2 s	Cold start: 26 s Hot start: 2 s Reacquisition: 2 s
Single Point Positioning Accuracy (RMS)	Horizontal: 1.5 m (open sky) Vertical: 2.5 m (open sky)	Horizontal: 1.5 m (open sky) Vertical: 2.5 m (open sky)
RTK Positioning Accuracy (RMS)	Horizontal: 1 cm + 1ppm (open sky) Vertical: 2 cm + 1ppm (open sky)	Horizontal: 1 cm + 1ppm (open sky) Vertical: 2 cm + 1ppm (open sky)
Velocity Accuracy (RMS) ⁴	0.05 m/s	0.05 m/s
Sensitivity	Tracking: -162 dbm Cold start: -147 dbm Hot start: -157 dbm Reacquisition: -158 dbm	Tracking: -162 dbm Cold start: -147 dbm Hot start: -156 dbm Reacquisition: -158 dbm
Data Update Rate	1 Hz/5 Hz/10 Hz	1 Hz/5 Hz/10 Hz
1PPS Accuracy (RMS)	20 ns	20 ns
Data Format	NMEA 0183 Unicore Protocol RTCM	NMEA 0183 Unicore Protocol RTCM
Electrical Specifications		
Voltage	2.7 V to 3.6 V, Typ.: 3.3 V	2.7 V to 3.6 V, Typ.: 3.3 V
LNA Feed Power	2.7 V to 3.3 V, <100 mA	2.7 V to 3.3 V, <100 mA
Power Consumption	240 mW	240 mW

⁴ 68% at 30 m/s for dynamic operation, open sky

Environmental Specifications		
Humidity	95% No condensation	95% No condensation
Vibration	GB/T 28046.3; ISO 16750.3	GB/T 28046.3; ISO 16750.3
Shock	GB/T 28046.3; ISO 16750.3	GB/T 28046.3; ISO 16750.3

1.2 Block Diagram




Figure 1-2 UM680A Block Diagram

1. RF Part

The receiver gets filtered and enhanced GNSS signals from the antenna via a coaxial cable. The RF part converts the RF input signals into the IF signals, and converts IF analog signals into digital signals required for UFirebird II chip.

2. UFirebird II SoC (UC6580A)

UFirebird II is the new generation RF-baseband and high-precision algorithm integrated SoC developed by Unicore. It adopts 22 nm technology and low power consumption design, supporting multi-path mitigation, anti-jamming and high precision GNSS joint positioning. The chip is especially suitable for the application scenarios which are sensitive to power and size.

3. Interfaces

UM680A has interfaces such as UART, I²C*, SPI*, PPS, EVENT, RTK_STAT and RESET_N.

There are two UARTs. UART1 is the master serial port, supporting data transmission and firmware upgrade, and the I/O signal type is LVTTL. The baud rate can be configured by users. UART2 is a backup and only supports data transmission. It is unavailable for firmware upgrade.

* I²C and SPI are reserved interfaces.

2 Hardware

2.1 Pin Definition

See Figure 2-1 for the definition of UM680A-12/UM680A-13.




Figure 2-1 UM680A-12/UM680A-13 Pin Definition

Table 2-1 UM680A-12/UM680A-13 Pin Definition

No.	Pin	I/O	Description
1	GND	—	Ground
2	RF_IN	I	GNSS antenna signal input
3	GND	—	Ground
4	ANT_DETECT	I	Active antenna detection. Active high. High = antenna detected; Low = antenna not detected.
5	ANT_OFF	O	Disable external antenna power supply. Active high. High = disable external antenna; Low = enable external antenna.

No.	Pin	I/O	Description
6	ANT_SHORT_N	I	Active antenna short detection. Active low. Low = antenna short circuit; High = antenna power status normal.
7	VCC_RF ⁵	O	Antenna feed output
8	SPIM_CS	—	Chip select pin for SPI master
9	SPIM_MOSI	O	Master Out / Slave In. This pin is used to transmit data in master mode.
10	SPIM_CLK	—	Clock input pin for SPI master
11	SPIM_MISO	I	Master In / Slave Out. This pin is used to receive data in master mode.
12	GND	—	Ground
13	RSV	—	Reserved, leave floating.
14	GND	—	Ground
15	RSV	—	Reserved, leave floating.
16	RSV	—	Reserved, leave floating.
17	RSV	—	Reserved, leave floating.
18	RSV	—	Reserved, leave floating.
19	RSV	—	Reserved, leave floating.
20	RTK_STAT	O	RTK positioning indicator, active high. High = RTK fix; Low = other status.
21	RSV	—	Reserved, leave floating.
22	RSV	—	Reserved, leave floating.
23	RSV	—	Reserved, leave floating.
24	RSV	—	Reserved, leave floating.
25	RSV	—	Reserved, leave floating.
26	RXD2	I	UART2 input, LVTTTL level
27	TXD2	O	UART2 output, LVTTTL level
28	RSV	—	Reserved, leave floating.
29	RSV	—	Reserved, leave floating.
30	RSV	—	Reserved, leave floating.

⁵ Not recommended to use VCC_RF to feed the antenna (VCC_RF is not optimized for the anti-lightning strike and anti-surge due to the compact size of the module).

No.	Pin	I/O	Description
31	RSV	—	Reserved, leave floating.
32	GND	—	Ground
33	VCC	I	Power supply (+3.3 V)
34	VCC	I	Power supply (+3.3 V)
35	RSV	—	Reserved, leave floating.
36	V_BCKP	I	When the main power supply VCC is cut off, V_BCKP supplies power to RTC and relevant register. Supply voltage: 2.0 V to 3.6 V, and the working current is less than 10 μ A at 25 °C. If you do not use the hot start function, connect V_BCKP to VCC or a standalone power source. Do NOT connect it to ground or leave it floating.
37	GND	—	Ground
38	RSV	—	Reserved, leave floating.
39	RSV	—	Reserved, leave floating.
40	RSV	—	Reserved, leave floating.
41	GND	—	Ground
42	TXD1/SPIS_MISO	O	UART1 output (D_SEL=VCC or floating); Master In/Slave Out of SPI slave (D_SEL=GND)
43	RXD1/SPIS_MOSI	I	UART1 input (D_SEL=VCC or floating); Master Out/Slave In of SPI slave (D_SEL=GND)
44	SDA/SPIS_CSN	I	I ² C data (D_SEL=VCC or floating); SPI slave chip select (D_SEL=GND)
45	SCL/SPIS_CLK	I	I ² C clock (D_SEL=VCC or floating); SPI slave clock (D_SEL=GND)
46	RSV	—	Reserved
47	D_SEL	I	Interface select pin; Use pin 42 to 45 as a SPI slave when D_SEL = GND, as UART1 and I ² C When D_SEL=VCC or floating
48	GND	—	Ground
49	RESET_N	I	System reset; active low; the active time should be no less than 5 ms
50	RSV	—	Reserved, leave floating.

No.	Pin	I/O	Description
51	EVENT	I	Event mark input with adjustable frequency and polarity
52	RSV	—	Reserved, leave floating.
53	PPS	O	Pulse per second with adjustable pulse width and polarity
54	RSV	—	Reserved, leave floating.

2.2 Electrical Specifications

2.2.1 Absolute Maximum Ratings

Table 2-2 Absolute Maximum Ratings

Parameter	Symbol	Min.	Max.	Unit	Remark
Power Supply	VCC	-0.2	3.6	V	
Backup Battery	V_BCKP	-0.2	3.6	V	
Digital Pin Voltage		-0.2	3.6	V	
Antenna RF Input Power	RF_IN	-	-3	dBm	
Storage Temperature	T _{STG}	-40	+85	°C	UM680A-12
	T _{STG}	-40	+105	°C	UM680A-13
Reflow Soldering Temperature	T _{SLDR}	-	+245	°C	

2.2.2 Operational Conditions

Table 2-3 Operational Conditions

Parameter	Symbol	Min.	Typ.	Max.	Unit	Condition
Power Supply	VCC	2.7	3.3	3.6	V	
VCC Ripple	Vp-p			50	mV	
Peak Current	I _{ccp}			200	mA	VCC = 3.0 V
Average Tracking Current ⁶	I _{ACQ}	70	80	100	mA	VCC = 3.0 V
Low Level Input Voltage	V _{IL}	-0.3		0.2 × VCC	V	
High Level Input Voltage	V _{IH}	0.7 × VCC		3.6	V	
Low Level Output Voltage	V _{OL}	0		0.4	V	I _{out} = -2 mA
High Level Output Voltage	V _{OH}	VCC – 0.4		V _{CC}	V	I _{out} = 2 mA
Antenna Gain	G _{ANT}	15	20	30	dB	

⁶ Since the product has capacitors inside, inrush current occurs during power-on. You should evaluate in the actual environment in order to check the effect of the supply voltage drop caused by inrush current in the system.

2.3 Dimensions

Table 2-4 Dimensions

Symbol	Min. (mm)	Typ. (mm)	Max. (mm)
A	21.80	22.00	22.50
B	16.80	17.00	17.50
C	2.40	2.60	2.80
D	3.75	3.85	3.95
E	0.95	1.05	1.15
F	1.80	1.90	2.00
G	1.00	1.10	1.20
H	0.70	0.80	0.90
K	1.40	1.50	1.60
M	3.55	3.65	3.75
N	3.15	3.25	3.35
P	2.00	2.10	2.20
R	1.00	1.10	1.20
X	0.72	0.82	0.92




Figure 2-2 UM680A Mechanical Dimensions

3 Hardware Design

3.1 Recommended Minimal Design





Figure 3-1 UM680A Recommended Minimal Design

Remarks:

- L1: 68 nH RF inductor in 0603 package is recommended
- C1: 100 nF + 100 pF capacitors connected in parallel is recommended
- C2: 100 pF capacitor is recommended
- C3: Several 10 μ F + 100 nF capacitors connected in parallel is recommended
- C4: 100 nF capacitor is recommended
- R1: 10 k Ω resistor is recommended, pull up

3.2 Antenna Feed Design

UM680A just supports feeding the antenna from the outside of the module rather than the inside. It is recommended to use devices with high power and that can withstand high voltage. Gas discharge tube, varistor, TVS tube and other high-power protective devices may also be used in the power supply circuit to further protect the module from lightning strike and surge.

 If the antenna feed supply ANT_BIAS and the module's main supply VCC use the same power rail, the ESD, surge and overvoltage from the antenna will have an effect on VCC, which may cause damage to the module. Therefore, it is recommended to design an independent power rail for the ANT_BIAS to reduce the possibility of module damage.




Figure 3-2 UM680A External Antenna Feed Reference Circuit

Remarks:

- L1: feed inductor, 68nH RF inductor in 0603 package is recommended;
- C1: decoupling capacitor, it is recommended to connect two capacitors of 100nF/100pF in parallel;
- C2: DC blocking capacitor, recommended 100pF capacitor;
- Not recommended to take VCC_RF as ANT_BIAS to feed the antenna (VCC_RF is not optimized for the anti-lightning strike and anti-surge due to the compact size of the module)
- D1: ESD diode, choose the ESD protection device that supports high frequency signals (above 2000 MHz)
- D2: TVS diode, choose the TVS diode with appropriate clamping specification according to the requirement of feed voltage and antenna voltage

3.3 Antenna Detection Design

UM680A supports the detection of open circuit and short circuit, and it will cut the antenna feed supply when a short circuit happens. The antenna detection circuit is connected to the pins of ANT_DETECT, ANT_SHORT_N and ANT_OFF, the voltage level of which can be used to judge the antenna status.

 Refer to UM680A Hardware Reference Design for the details of the antenna detection circuit.

3.4 Power-on and Power-off

VCC

- The VCC initial level when power-on should be less than 0.4 V.
- The VCC ramp when power-on should be monotonic, without plateaus.
- The voltages of undershoot and ringing should be within 5% VCC.
- VCC power-on waveform: The time interval from 10% rising to 90% must be within 100 μ s to 10 ms.
- Power-on time interval: The time interval between the power-off ($V_{CC} < 0.4$ V) to the next power-on must be larger than 500 ms.

V_BCKP

- The V_BCKP initial level when power-on should be less than 0.4 V.
- The V_BCKP ramp when power-on should be monotonic, without plateaus.
- The voltages of undershoot and ringing should be within 5% V_BCKP.
- V_BCKP power-on waveform: The time interval from 10% rising to 90% must be within 100 μ s to 10 ms.
- Power-on time interval: The time interval between the power-off ($V_{BCKP} < 0.4$ V) to the next power-on must be larger than 500 ms.

3.5 Grounding and Heat Dissipation




Figure 3-3 Grounding and Heat Dissipation Pad

The 48 pads in the rectangle in **Figure 3-3** are for grounding and heat dissipation. In the PCB design, it is recommended to connect them to a large sized ground to strengthen the heat dissipation.

3.6 Recommended Footprint on the PCB

The dimensions of UM680A's footprint on the PCB is recommended to be the same as that of the module's pads, as shown in **Figure 3-4 Recommended Footprint**. For more information about the module's dimensions, see **2.3 Dimensions**.

- ☞ For the convenience of hardware testing and debugging, proper test points can be added for the functional pins of the module.
- ☞ The dimensions of PCB pads can be optimized according to the specific production process to ensure manufacturability and reliability.




Figure 3-4 Recommended Footprint (Unit: mm)

4 Production Requirements

4.1 Clean



Do NOT use alcohol or other organic solvents to clean the module, or it may lead to flux residues entering into the shielding shell, causing mildew and other problems.

4.2 Soldering

Recommended soldering temperature curve is as follows:




Figure 4-1 Soldering Temperature (Lead-free)

Temperature Rising Stage

- Rising slope: Max. 3 °C/s
- Rising temperature range: 50 °C to 150 °C

Preheating Stage

- Preheating time: 60 s to 120 s
- Preheating temperature range: 150 °C to 180 °C

Reflux Stage

- Over melting temperature (217 °C) time: 40 s to 60 s
- Peak temperature for soldering: no higher than 245 °C

Cooling Stage

- Cooling slope: Max. 4 °C/s



In order to prevent falling off during soldering of the module, do not solder it on the back of the board during design, that is, better not go through soldering cycle twice.

The setting of soldering temperature depends on many factors of the factory, such as board type, solder paste type, solder paste thickness, etc. Please also refer to the relevant IPC standards and indicators of solder paste.

4.3 Stencil

The apertures in the stencil need to meet the customer's own design requirements and inspection specifications. The thickness of the stencil is recommended to be 0.15 mm (not less than 0.12 mm).



The design of the stencil can be optimized according to the specific production process to ensure manufacturability and reliability.

5 Packaging

5.1 Label Description



Figure 5-1 Label Description

5.2 Ordering Information

Product Model	Sub-model	Description
UM680A	12	Automotive grade; dual-frequency RTK positioning module; operating temperature: -40 °C to +85 °C; supporting firmware upgrade; 22 mm x 17 mm; 250 pieces/reel
	13	Automotive grade; dual-frequency RTK positioning module; operating temperature: -40 °C to +105 °C; supporting firmware upgrade; 22 mm x 17 mm; 250 pieces/reel

5.3 Product Packaging

The UM680A module uses carrier tape and reel (suitable for mainstream surface mount devices), packaged in vacuum-sealed aluminum foil antistatic bags, with a desiccant inside to prevent moisture. When using reflow soldering process to solder modules, please strictly comply with IPC standard to conduct humidity control. As packaging materials such as the carrier tape can only withstand the temperature of 55 °C, modules shall be removed from the package during baking.



Figure 5-2 UM680A Package





Figure 5-3 UM680A Reel Package Diagram

Table 5-1 Package Description

Item	Description
Module Number	250 pieces/reel
Reel Size	Tray: 13" External diameter: 330 ± 2 mm Internal diameter: 180 ± 2 mm Width: 44.5 ± 0.5 mm Thickness: 2.0 ± 0.2 mm
Carrier Tape	Space between (center-to-center distance): 24 mm

Before surface mounting, make sure that the color of the 30% circle on the HUMIDITY INDICATOR is blue (see Figure 5-4). If the color of the 20% circle is pink and the color of the 30% circle is lavender (see Figure 5-5), you must bake the module until it turns to blue. The UM680A is rated at MSL level 3. Refer to the relevant IPC/JEDEC J-STD-033 standards for the package and operation requirements. Users may access to the website www.jedec.org to get more information.




Figure 5-4 Normal Humidity Indication




Figure 5-5 Abnormal Humidity Indication

The shelf life of the UM680A module packaged in vacuum-sealed aluminum foil antistatic bags is one year.

和芯星通科技（北京）有限公司

Unicore Communications, Inc.

北京市海淀区丰贤东路 7 号北斗星通大厦三层
F3, No.7, Fengxian East Road, Haidian, Beijing, P.R.China,
100094

www.unicore.com

Phone: 86-10-69939800

Fax: 86-10-69939888

info@unicorecomm.com



www.unicore.com